



Toe Plates Instructions

This is a fast way to check / set front end toe. It is affected by wheel or tire runout. Be certain wheels run true and tires have no bulges.

- **Turn wheels to straight ahead:** Should be done on level ground. Set caster & camber first.
- **Lean plates up against wheels:** Folded lip goes to the outside. Be sure the entire plate is up against the wheel.
- **Measure front width, then rear:** Use the slots for the tape measure. Subtract one from the other for toe. Larger front width means toe-out.